

## SPARE PARTS QUICK REFERENCE GUIDE

# JACK PACKINGS

JACK SIZE	SEAL KIT PART NUMBER	CHECK VALVE	CHECK VALVE PART NUMBER	NOTES
2S	9851082	No		
3S	9851094	No		
4S	9851008*	No		*if the seal print number from job file is alphanumeric If it is all numbers, you will need part # 9803701.
5S	9851010*	No		*if the seal print number from job file is alphanumeric If it is all numbers, you will need part # 9803713.
6S	9851021*	No		*if the seal print number from job file is alphanumeric If it is all numbers, you will need part # 9803725.
7S	9740855	No		
8S	9863952	No		
2.5T	9735343	Yes*	9723215	*1 check valve per jack/side
3.0T	9728983	Yes*	9723215	*1 check valve per jack/side
2.5T III (3-Stage)	9862741	Yes*	9723215	*2 check valves per jack/side